

# TOOLBOX TALKS

## MACHINE SAFETY – SUBMERSION

Toolbox Talks are designed to promote safety discussions and best practices on the jobsite. To see more Toolbox Talks, please visit [hollandcs.com/toolboxtalks](https://hollandcs.com/toolboxtalks).

## MACHINE SAFETY – SUBMERSION

### WHAT TO DO:

- Stop the machine
- Shift to Neutral
- Set the parking brake
- Summon help
- Stay in the cab if you are above the waterline and wait for help to arrive
- If the cab is below the waterline, neutralize the water pressure by opening a window. Exit machine as quickly and safely as possible

The material in this document is provided for informational purposes only and not as a comprehensive or exhaustive resource on this topic. This material has been compiled from a multitude of sources believed to be accurate; however, Holland assumes no responsibility for the accuracy or currency of this information and encourages you to consult experts in this area for more information. In no event does the content of this document supersede any applicable local, state or federal statutes or regulations.



*A Better Way*  
• TO BUILD •